



Components

Num	Component	Drawing	Qty	Location of Fabrication
1	Outrigger beam	P13	2	GTS Canada
2	Outrigger fuse and connectors	P16	4	GTS Canada
3	Column lateral support	P15	4	GTS Canada
4	Mass block	P04,P07	8	China
5	Mass block angle	P04,P07	32	GTS Canada
6	Outrigger column and connections	P16,P17	4	GTS Canada
7	PT channels inside the wall	P12	4	GTS Canada
8	Wall to wall connection	P14	2	Canada
9	Coupling beam	P09	32	GTS Canada
10	Base fuse and connectors	P10	4	GTS Canada
11	Foundation	P03	1	China
12	Foundation anchors	P03	12	GTS Canada
13	Base armoring	P11	2	GTS Canada
14	Foundation angle	P03	6	GTS Canada

Material Properties

Unless otherwise specified in the drawings, materials for all components should be:

Steel:
ASTM A36 for steel plates;
G40.21 300W for angles;
ASTM A572- Gr50 for hot-rolled W, M, HP, and channel sections
ASTM A500 - Gr50 for HSS sections



Threaded Rods:
ASTM F1554-Gr105 for threaded rods (no welding required);
ASTM F1554-Gr55 for threaded rods (welding required);


Bolts:
ASTM A490 for bolts to connect coupling beams
ASTM A325 for other bolts

Rebars and PT:
Gr60 for rebars;
ASTM A416-Gr270 for strands in PT tendons


Concrete:
f'c = 45 Mpa, from 28 day concrete cylinder tests
For the concrete core wall channels:
the clear cover is 5/16"; the max. aggregate size is 1/4".
For all mass blocks and the foundation :
the clear cover is 1 3/16" and the max. aggregate size is 3/4".

Typical Development Length of Reinforcement





Shake table test



Bottom wall component
Qty: 2
Unit Weight: 60kN/13.5kips

Top wall component
Qty: 2
Unit Weight: 30kN/6.75kips

Material Properties

Unless otherwise specified in the drawings, materials for all components should be:

Threaded Rods:

ASTM F1554-Gr105 for threaded rods (no welding required);
ASTM F1554-Gr55 for threaded rods (welding required);

Bolts:

ASTM A490 for bolts to connect coupling beams
ASTM A325 for other bolts

Rebars and PT:

Gr60 for rebars;
ASTM A416-Gr270 for strands in PT tendons

Concrete:

$f'_c = 45$ Mpa, from 28 day concrete cylinder tests

For the concrete core wall channels:


the clear cover is 5/16"; the max. aggregate size is 1/4".

For all mass blocks and the foundation :


the clear cover is 1 3/16" and the max. aggregate size is 3/4".


Typical Development Length of Reinforcement

#2 Rebars:




1/8" Wires:





Bottom wall component
Qty: 2
Unit Weight: 60kN/13.5kips



Top wall component
Qty: 2
Unit Weight: 30kN/6.75kips




SHEET NO.

1


DRAWN BY

Tianyang Qiao
Hengchao Xu
Lisa Tobber


DATE	2023/10/08




PT anchor - Type I
Qty: 1
Unit Weight: 3.5kN/0.8kips




PT anchor - Type II
Qty: 1
Unit Weight: 3.5kN/0.8kips




Mass block support
Qty: 32
Unit Weight: 0.3kN/0.065kips




Outrigger end connection
Qty: 4
Unit Weight: 0.2kN/0.04kips



Outrigger end connection
Qty: 4
Unit Weight: 0.14kN/0.03kips




Base fuse
Qty: 4
Unit Weight (without fuse): 1.1kN/0.25kips




Foundation shear angle (Formed by 3/4" Thk plate)
Qty: 6
Unit Weight: 2.4kN/0.54kips

Outrigger
Qty: 1
Unit Weight: 16.8kN/3.8kips




22' - 11 3/8"




Outrigger column - Type I
Qty: 4
Unit Weight: 3.1kN/0.7kips

22' - 11 3/8"




Outrigger column - Type II
Qty: 4
Unit Weight: 3.1kN/0.7kips



L 2 1/2 X 2 1/2 X1/4
W 6X16



Column lateral support
Qty: 4
Unit Weight: 0.75kN/0.17kips



Friction Device
Qty: 16
Unit Weight: 0.2kN/0.04kips



Foundation shear angle (Formed by 3/4" Thk plate)
Qty: 6
Unit Weight: 2.4kN/0.54kips

ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING






Components in 3D View





SHEET NO.	
4	
DRAWN BY	
Tianyang Qiao Hengchao Xu Lisa Tobber	
DATE	2023/10/08

Steel Components List

Manufactured by GTS

Ready for Fabrication

Num	Component	Figure	Qty	Drawing
1	Outrigger		1	S1-1
2	Outrigger column lateral support		4	S2
3	Outrigger columnc Type I		4	S3-1
4	Outrigger columnc Type II		4	S3-1
5	Outrigger end connection Type I		8	S3-2
6	Outrigger end connection Type II		4	S3-2
7	Wall base armoring		2	S4-1/S4-2
8	Steel embedded beam		32	S5
9	Foundation anchor Type I		4	S6-1
10	Foundation anchor Type II		2	S6-2
11	Mass block support		32	S7
12	PT anchor Type I		1	S8-1/S8-3
13	PT anchor Type II		1	S8-2/S8-3


Num	Component	Figure	Qty	Drawing
14	Wall to wall connection Type I		2	S9
15	Wall to wall connection Type II		2	S9
16	Base fuse connection		4	S10
17	PT base anchor plate		1	S11
18	Friction damper		16	S12 UnderTest

Standard Section Used


Num	Section Type	Total Length
1	W 14X120	28'-2"
2	W 8X15	24'-8"
3	W 6X16	30'-4"
4	L 8X6X3/4	32'
5	L 2.5X2.5X1/4	61'-3 3/4"
6	HSS 6X6X3/8	45'-10 3/4"
7	C12X30	22'-3"

Material Properties

Steel:
ASTM A36 for steel plates;
G40.21 300W for angles;
ASTM A572- Gr50 for hot-rolled W, M, HP, and channel sections
ASTM A500 - Gr50 for HSS sections
Threaded Rods:
ASTM F1554-Gr105 for threaded rods (no welding required);
ASTM F1554-Gr55 for threaded rods (welding required);
Bolts:
ASTM A325 for bolts



Qty: 1






Qyt: 4


Notes for GTS:

The purpose of this column lateral support is to provide stability to outrigger columns.


Currently, as shown in the figure, there are three angles welded at the top of the I-beam and another three welded at the bottom of the I-beam. They don't have to be in this exact configuration. So, if there is an easier way to construct this, please let us know.








* Ø11/16" hole for 5/8" bolt
** Drill Ø15/16" hole for 7/8" bolt




HSS 6X6X3/8
Qty: 4




HSS 6X6X3/8
Qty: 4




* Ø15/16" hole for 7/8" bolt
** Ø11/16" hole for 5/8" bolts
*** Drill Hole for Ø 1 1/2" pin with tolerance less than 1/32", the less the better




Type I
Qty: 8



Type II
Qty: 4




Type I









Type II

* Ø11/16" hole for 5/8" threaded rods
** Drill Hole for Ø 1 1/2" pin with tolerance less than 1/32", the less the better




Qty: 2





Notes for GTS:

Based on the conversation with Rob, we need steel components to connect the beam to the form work. Please add as you see fit.




Qty: 32






Type I
Qty: 6




Qty. 4




Type II
Qty: 6


Note: To match metric hole pattern in China, length and width are using metric unit, except the thickness, which is 3/4"




Qty. 2






Type I
Qty: 1





Type II
Qty: 1








****Notes:**
If possible, use A325M bolts instead of rods

* Ø15/16" hole for 7/8" threaded rods


** Slot with Ø1/16" clearance for 7/8" bolt



*** Ø15/16" hole for 7/8" bolt




Wall to wall connection plate - Type I
3/4" Thk plate
Qty: 2
Unit Weight: 0.38kN/0.083kips




Note: Weld to develop full strength of rebar

1 S9 Thk 3/4" Plate

Qty. 1




Wall to wall connection plate - Type II
3/4" Thk plate
Qty: 2
Unit Weight: 0.44kN/0.098kips




Note: Weld to develop full strength of rebar

2 S9 Thk 3/4" Plate


Qty. 1




Qty: 4




A



B




C




D


*** Notes:
If possible, use A325M bolts instead of rods
* Ø11/16" hole for 5/8" threaded rods
** Ø1 1/16" holes for 1" all-threaded rods
*** Drill Hole for Ø 1 1/2" pin with tolerance less than 1/32", the less the better



- Waiting on the PT mounting detail from Dywidag to confirm the correct hole pattern

Qyt: 1





UNDER REVISION



ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING

Temporary Truss for Lifting

SHEET NO.

S12

DRAWN BY

Tianyang Qiao
Hengchao Xu
Lisa Tobber

DATE	2023/10/08
------	------------

8 #3

#2 @ 1 3/4 " V.E.F
#2 @ 3 1/2 " H.E.F

#2 @ 4 1/2 " V.E.F
#2 @ 4 1/2 " H.E.F

8 #3



THE UNIVERSITY
OF BRITISH COLUMBIA
Smart Structures

ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING

Wall to Wall Connection


SHEET NO.

S9


DRAWN BY

Tianyang Qiao
Hengchao Xu
Lisa Tobber


DATE	2023/10/08
------	------------




Qty: 4




A



B



C



D

*** Notes:
If possible, use A325M bolts instead of rods
* Ø11/16" hole for 5/8" threaded rods
** Ø1 1/16" holes for 1" all-threaded rods
*** Drill Hole for Ø 1 1/2" pin with tolerance less than 1/32", the less the better

ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING

Base Fuse Connection

SHEET NO.


S10-R1

DRAWN BY



Tianyang Qiao
Hengchao Xu
Lisa Tobber

DATE


2018/11/07





Qyt: 32



* Ø15/16" hole for 7/8" bolts
** Ø1 1/16" hole for 1" bolts



Qty: 32



ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING

**Mass Block Support
& Rebar End Zone Plate**

SHEET NO.

S7-R2

DRAWN BY

Tianyang Qiao
Hengchao Xu
Lisa Tobber


DATE

2018/11/08




THE UNIVERSITY
OF BRITISH COLUMBIA



Smart Structures



Qty: 32



A



B

* Ø15/16" hole for 7/8" bolts

ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING

**Mass Block Support
& Rebar End Zone Plate**

SHEET NO.

S7-R3

DRAWN BY

Tianyang Qiao
Hengchao Xu
Lisa Tobber

DATE


2018/11/08


THE UNIVERSITY
OF BRITISH COLUMBIA

Smart Structures




Based on the conversation with Rob, we need steel components to connect the beam to the form work. Please add as you see fit.







Qty: 32



A








B



C

* Ø15/16" hole for 7/8" bolts
** #6 rebar welded on, drill a hole if necessary



ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING

**Mass Block Support
& Rebar End Zone Plate**


SHEET NO.

S7

DRAWN BY

Tianyang Qiao
Hengchao Xu
Lisa Tobber

DATE	2018/11/11



DRAWN BY

Tianyang Qiao
Hengchao Xu
Lisa Tobber

SHEET NO.

S7


ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING

Mass Block Support
& Rebar End Zone Plate




THE UNIVERSITY
OF BRITISH COLUMBIA


Smart Structures




Qty: 4




A



B



C




D

*** Notes:
If possible, use A325M bolts instead of rods
* Ø11/16" hole for 5/8" threaded rods
** Ø1 1/16" holes for 1" all-threaded rods
*** Drill Hole for Ø 1 1/2" pin with tolerance less than 1/32", the less the better

ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING


SHEET NO.
S10-R1
DRAWN BY
Tianyang Qiao
Hengchao Xu
Lisa Tobber

DATE	2023/10/08



Qty: 32

L 8X6X3/4



ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING

Mass Block Support

SHEET NO.


M109R1

DRAWN BY

Tianyang Qiao
Hengchao Xu
Lisa Tobber

DATE

2018/11/30



Qyt: 8

M121



THE UNIVERSITY
OF BRITISH COLUMBIA
Smart Structures

ILEE-EERF COLLABORATIVE SHAKE-TABLE TEST
NEXT-GENERATION EARTHQUAKE RESILIENT TALL BUILDING

Base Fuse Connection

SHEET NO.

M121R1

DRAWN BY

Tianyang Qiao
Hengchao Xu
Lisa Tobber

DATE	2018/11/30
------	------------
